



Escort, Beltronics, and Valentine 1 Power Cords For Powered Mirrors

These cords will fit various models of the Whistler, Escort, Beltronics, AND the Valentine 1. For other types and years of vehicles not listed below, if you have a voltmeter, it is probably safest to find the pins in your mirror connector that are positive and negative. Please check the installation chart below for your particular application. These are as reported back from prior customers.

For actual pictures of installations by customers and for better visuals of how to install the Invisicord, please visit www.invisicord.com/gallery!

Legal disclaimer: I cannot be held responsible for any damage to your detector or vehicle if this is wired incorrectly. If you do not agree to these terms, please do not use this product and return it for a refund. If you are unsure you have the correct wires, please try testing the voltage and polarity of the wires you are going to tap into before plugging the RJ11 plug in the detector. Directions are supplied by prior customers of this product.

Nissan/Infiniti

Vehicle Model/Type	InvisiCord +12v YELLOW wrap	InvisiCord GND BLACK wrap
2004+ Infiniti FX35	Black w/Red	Black
Infiniti G35, w/homelink	Black w/Pink OR brown for 2007+	Black
Nissan 350Z, w/homelink	Black w/Pink OR brown for 2007+	Black
2007 Nissan Maxima	Orange	Black
2006+ M35/M45	Black/Yellow (or Brown, 2 versions)	Black
2008+ Nissan Rogue	Black w/Red	Black
2008+ Nissan Altima	Black w/Red	Black

Chevrolet Corvette

97, 98 ???, 99 C5 Corvette Standard (Doors MUST be closed)	Orange	Black
00+ C5 Corvette Autodim (Doors MUST be closed)	Brown	Orange (2 nd wire in)
C6 Corvette Autodim (vehicle must be running)	Lower Middle Pink	Black, top row
C6 Corvette Standard	Top Row Orange	Top Row Black

Cadillac

Pre-2008 Cadillac Escalade	2 nd Yellow Farthest From Black	Black
2008+ Cadillac Escalade	Lower Middle Pink,	Black, top row
2005+ Cadillac STS Autodim	Lower Middle Pink	Black, top row
2006+ Cadillac CTS-V (have to remove cosmetic harness cover)	Pink	Braided bare silver
2009 Cadillac CTS	Yellow	Black/White

Toyota/Lexus

Lexus RX 330	Passenger End 1 st Black	Passenger End 2 nd Black
--------------	--	--

Honda/Acura

2004 Acura TSX	Black/Yellow, end	Black, middle
2005 Honda Odyssey	Black/Yellow, end	Black, middle

Ford

2003 Expedition Edie Bauer	Port #1, driver side	Port #2, driver side
2007 Ford Mustang (2005/2006 TBD?)	Purple	Black

Subaru

2004+ Legacy and Impreza	Black/white, top row, pin 1	Pin 9, bottom row, 2 nd from end
--------------------------	--------------------------------	--

General Motors Passenger

Vehicle Model/Type	InvisiCord +12v YELLOW wrap	InvisiCord GND BLACK wrap
2004+ Malibu/Malibu Maxx Autodim	Blue w/White	Black
2004+ Pontiac G6 Autodim	Blue w/White	Black
Saturn Vue	Middle Yellow, lower row	Black, top row
2001-2005 Monte Carlo	Bottom solid brown	Top end black
2006 Impala SS	Yellowish White, 4 th wire, top left	Black, end top right
2008+ Acadia/Outlook/Enclave	Black w/Yellow, 4 th bottom row wire	Black, top row

General Motors Trucks

2003+ Silverado SS, GMC 2500 Compass/Autodim/Temp	Middle Yellow, left column	Top Black, right column
2008+ Silverado	Pink, left wire	Black, top wire
2007 Tahoe	Middle Yellow, left column	Top Black, right column
Hummer H2	Black, top row w/4 wires	Brown, middle bottom row
2006 Trailblazer SS Autodim	Lower Middle Pink	Black, top row
2007 Avalanche	Lower Middle Pink	Black, top row
Colorado w/3LT pkg	Orange	Black
2007+ GMC Denali	Yellow	Black

Chrysler/Dodge/Jeep

Chrysler wUConnect (SRT8, 300C, etc)	Lower flat rectangular plug, wire on far passenger end	Lower flat rectangular plug, wire 2nd in from passenger end
2001-2004 Jeep Cherokee Non-UConnect	Pin #1 in 7 Pin Harness, black w/colored stripe	Pin #2 in 7 Pin Harness, black
2008 Jeep Cherokee SRT8 Smart Beams	Driver 2 nd from bottom, pinkish white?	Passenger bottom black
2006 Chrysler 300-C (Heritage Edition)	Red/Black, bottom connector	Green/Black, bottom connector
2006 Viper GTS	Pin #2, end toward driver	Pin #7, end toward passenger
2007 Ram Laramie	Red	Black

Panoz

2002-2005+ Panoz	Pink	Black
------------------	------	-------

Directions:

- 1) Pull the mirror around so that you can access the power plug in the back, or unplug the harness if it would seem to help.
- 2) Push the +12v pin connection (see chart above) into the back of the slot that is determined to the hot +12v on the mirror wiring harness.
- 3) Push the ground connection (see chart above) into back of the slot that is determined to the ground on the mirror wiring harness.
- 4) If you have a mirror that has a switched power source (standard mirrors typically do not), mount the detector within reach of the power cord. Turn on the detector, and turn on/off the ignition to check the power and connection quality. You should see your detector power up and back down with the ignition.
- 5) Once you have power to the detector, please use a cable-tie around the Invisicord and the factory wiring to help keep the connectors from coming free due to vibration or the detector suction mount giving way, which could damage the Invisicord leads going into the mirror.